



Note that on Rev 1 PCB, the third leg is connected to ground. For proper operation, the third leg of the potentiometer should be clipped (see build guide). As is, when the pot goes fully clockwise, it starts to short the op-amp, creating a hacked distortion effect.